

Jocelyn Warner

Wallpaper Hanging Instructions

Please read these instructions carefully before hanging this wallpaper. It is advisable that a professional decorator is used.

1 Inspect each roll

It is important to check each roll has the same batch number before cutting and hanging the wallpaper. Also check there is no variation in shade, and that no other faults are present. Please make sure there are enough rolls to complete the job. **Do not assume that the wallpaper will come off the roll the correct way up. Please see the image attached.**

Examination of the paper before hanging is the buyer's responsibility. No claims can be considered after papers have been cut and hung, for defects which are apparent at the time of hanging. In the event of any complaint, please quote the product code and batch number on this label. Return any defective roll with its label to where it was purchased.

2 Preparation

- Remove any old wallpaper and loose paint and ensure that any holes or cracks are suitably filled and rubbed smooth when dry. Walls should be sound, clean and dry.
- We recommend painted surfaces are roughened with sandpaper to improve adhesion.
- Absorbant surfaces (such as new plaster) should be prepared with a primer/sealer.
- Metallic effects and foils can be damaged if high levels of alkaline are already present in the walls (such as newly plastered walls). Preparing the walls with an alkaline resistant primer neutralises the alkalinity of the surface.
- For best results, we recommend that the walls are cross-lined horizontally using a good quality lining paper. The lining paper should be allowed to dry completely before hanging the wallpaper.

3 Pasting

- Use a good quality, solvent-free, fungicide protected, light grade adhesive. Do not use self-mix adhesives; all-purpose and heavy-duty pastes are also not suitable.
- Apply an even coat of paste to the wallpaper, ensuring edges are fully pasted. Do not allow paste to come into contact with the surface.
- Once pasted fold the pasted surfaces together, top to middle and bottom to middle, and allow sufficient time for the paper to become supple (4-5 minutes). Care should be taken not to crease the paper when folding.

4 Hanging

- Hang wallpaper, smooth gently down the centre with a paperhangers brush, working out towards the edges, brushing out air bubbles as you go.
- Butt joins tightly but do not ever overlap. Avoid squeezing paste out of joins and do not get paste on the brush, hands or seam roller.
- Paste may damage the surface of the wallpaper and cause surface printed colours to transfer. We cannot accept responsibility for marks or damage caused by paste.
- Any paste should be removed whilst still moist, by wiping gently across the entire surface using a clean, wet sponge.
- Trim top and bottom with a sharp knife or scissors.
- After hanging 2 or 3 lengths, inspect the result to ensure that no shading or other faults are present. No claims can be considered once more than one roll has been hung.

This information has been supplied in good faith, but without guarantee. Site conditions are beyond our control. It is the responsibility of the buyer to ensure that the environment is suitable for the wallpaper.

Jocelyn Warner



Hang Peony as a Straight Match. Repeat size is 91cm/35.8". Roll width 68.5cm/27", length is 10m/11yds. Please read the hanging instructions.